



DIAMOBILE XL™

A COMPACT AND MOBILE SYSTEM FOR EVALUATING
AND PLANNING ROUGH DIAMONDS

QUICK INSTALLATION GUIDE

by Sarin Technologies Ltd.

P/N 30-0001-16

Rev 1

Limited Warranty and Disclaimer

Sarin Technologies warrants this product to be free from defects in materials and workmanship under normal use for one year from purchase. All implied warranties and conditions (including any implied warranty of merchantability or fitness for a particular purpose) are disclaimed as to the product and this manual. Your exclusive remedy for breach of warranty will be the repair or replacement of this product or a refund of the purchase price at our discretion. In no event will Sarin Technologies Ltd. or its directors, officers, employees, or affiliates be liable to you for any consequential, incidental or indirect damages (including damages for loss of business, profits, business interruption, and the like), whether foreseeable or unforeseeable, arising out of the use or inability to use the product of this manual, regardless of the basis of the claim and even if Sarin Technologies Ltd. representative has been advised of the possibility of such damages.

Sarin Technologies Ltd. liability to you for actual damages for any cause whatsoever, and regardless of the form of the action, will be limited to the money paid for the product that caused the damages.

Copyright © 2007

All rights reserved. This document and the information contained herein belong to Sarin Ltd. ("Sarin") and may be used only as authorized by Sarin in writing. No part of this publication may be reproduced in any way without the prior written consent of Sarin.

This document is subject to change without notice.

Trademarks

The **Sarin**[®] and **Advisor**[™] names are registered trademarks of Sarin Ltd. All other brand and product names referred to herein are the trademarks of their respective owners.

Sarin Technologies Ltd.

Introduction

Congratulations on purchasing the **DiaMobile XL**, a compact and mobile system for evaluating and planning rough diamonds. Once you have installed the software and the calibration data you only need to plug it into any 110/220 Volt outlet and connect it to a USB port on your PC.

Do not connect machine to computer before software installation.

There are 2 optional software applications for the **DiaMobile XL**:


- 1- **Advisor™** - for rough planning
- 2- **DiaVision™** - for polished grading

Please install the applications you purchased as described in this document.

Advisor Installation


1. Load the **Advisor** installation CD into your PC CD/DVD reader, the installation should start automatically.


If not, open **My Computer**, right click the CD reader where you have loaded the Sarin Installation CD and click **Open**. From the displayed list of files, double click **Setup.exe**.




2. After reading the splash message, click the  button.




3. If agreeing with the license agreement, click the  button.





4. Select the programs you want to install.
5. Click the  button.
6. Ensure that the USB and power plugs are disconnected (as printed on the label).




7. Check if the machine serial number matches the number written on the disk.

If it matches, click the  button.

If it does not match, click the  button and call your Sarin technician.



8. Ensure that the USB and power cable is disconnected and then click the  button.




9. Click the  button to install the driver.



The installation was successful.


10. Click the  button to close the message box.




11. Click the  button to close the message box.



12. Select the language you want to install and Click the  button.



13. Click the  button (for future purpose).



14. Select the additional features and Click the  button.



15. You have successfully installed the new software and must now restart your computer

Click the  button to restart your computer.


16. Connect the DiaMobile XL to a 110/220Volt power outlet.


17. Ensure that the USB cable is not connected to your computer.
18. When the restart is completed, use the USB cable to connect the DiaMobile XL to your computer.

Connecting the DiaMobile XL invokes the **Found New Hardware Wizard** to complete the installation.



The **New Hardware Wizard** window opens as soon as you connect the DiaMobile XL to a USB port on your computer.

19. Select **No, not this time** (as shown above).
20. Click the  button.



21. Select **Install the software automatically**.


22. Click the  button.



The uEye camera installation starts.

23. Click the  button to continue.



24. Click the  button.




25. The **New Hardware Wizard** window opens again. Select **No, not this time** (as shown above).
26. Click the  button.




27. Select **Install the software automatically**.
28. Click the  button.



The uEye camera installation continues.

- 29. Click the  button to continue.



- 30. Click the  button to complete the DiaMobile XL installation.


Congratulations your program has been installed successfully.

If you encounter any problems whatsoever, please contact your local distributor.


DiaVision Installation


1. Load the **DiaVision** installation CD into your PC CD/DVD reader, the installation should start automatically.


If not, open **My Computer**, right click the CD reader where you have loaded the Sarin Installation CD and click **Open**. From the displayed list of files, double click **Setup.exe**.




2. After reading the splash message, click the  button.




3. If agreeing with the license agreement, click the  button.





4. Select the programs you want to install.
5. Click the  button.
6. Ensure that the USB and power plugs are disconnected (as printed on the label).




7. Check if the machine serial number matches the number written on the disk.

If it matches, click the  button.

If it does not match, click the  button and call your Sarin technician.



8. Ensure that the USB and power cable is disconnected and then click the  button.



9. Click the  button to install the driver.




The installation was successful.


10. Click the  button to close the message box.




11. Select the language you want to install and Click the  button.



12. Click the  button to enable ActiveX controls.



13. Select the additional features and Click the  button.



14. You have successfully installed the new software and must now restart your computer

Click the  button to restart your computer.


15. Connect the DiaMobile XL to a 110/220Volt power outlet.
16. Ensure that the USB cable is not connected to your computer.
17. When the restart is completed, use the USB cable to connect the DiaMobile XL to your computer.

Connecting the DiaMobile XL invokes the **Found New Hardware Wizard** to complete the installation.




The **New Hardware Wizard** window opens as soon as you connect the DiaMobile XL to a USB port on your computer.

18. Select **No, not this time** (as shown above).

19. Click the  button.



20. Select **Install the software automatically**.

21. Click the  button.



The uEye camera installation starts.

22. Click the  button to continue.



23. Click the  button.




24. The **New Hardware Wizard** window opens again.
Select **No, not this time** (as shown above).

25. Click the  button.



26. Select **Install the software automatically**.

27. Click the  button.



The uEye camera installation continues.

28. Click the  button to continue.



29. Click the  button to complete the DiaMobile XL installation.

Congratulations your program has been installed successfully.

If you encounter any problems whatsoever, please contact your local distributor.